

EVs | 27

The 27th **INTERNATIONAL
ELECTRIC VEHICLE
SYMPOSIUM & EXHIBITION.**

Barcelona, Spain
17th-20th November 2013

Application of the Thermal Impedance Spectroscopy method in 3 dimensions to a large prismatic Li-ion cell

Pierre-Luc Lapointe

Institut du Transport Avancé du Québec



Organized by



Hosted by



In collaboration with



Supported by



European Commission

eVS | 27 Summary

- Overview of the project
- TIS Method
- Model and test setup
- Results and observations
- Conclusion

Organized by



Hosted by



In collaboration with



Supported by



European Commission



ITAQ building
St-Jérôme, Québec

Tire Gantry
Crane



Organized by



Hosted by



In collaboration with



Supported by



Cell Capacity	42 Ah
Mass	1.4 kg
Cathode	LFP
Anode	Graphite
Dimensions	95x28x215 mm

Cell characteristics

Organized by



Hosted by



In collaboration with



Supported by



- The Thermal Impedance Spectroscopy is similar to Electrical Impedance Spectroscopy.
- The objective is to find the thermal impedance and fit the results to a model to obtain the thermal characteristics (C_p , k_x , k_y , k_z)
- The heat generation (Q) within the cell is the input signal and the surface temperature is the output signal (T_{surf})
- The thermal impedance can be defined as $Z = T_{surf}/Q$

Organized by



Hosted by



In collaboration with




Supported by




EVs | 27 TIS Method

There are many methods to generate heat within the cell.
We chose to use the cell electric resistance.



Current as a function of time (A)

$f = 0.016 \text{ Hz}$



Heat generation as a function of time (W)

$$Q = I|U-V|$$

Organized by



Hosted by



In collaboration with



Supported by



eVS | 27 TIS Method

To find the Thermal Impedance you either proceed with a time-domain or frequency-domain approach.

- Time-domain : 1 test processed with the fft algorithm
- Frequency-domain : Several tests with the heat generation at different frequencies

Organized by



Hosted by



In collaboration with



Supported by



European Commission

eVS | 27 Model

We used the Fourier law with the Finite Volume method to build the model

$$c_p \cdot \frac{dT(t)}{dt} = k_x \frac{dT(t)}{dx} + k_y \frac{dT(t)}{dy} + k_z \frac{dT(t)}{dz} + Q(t)$$

We applied the Laplace Transform (FFT) to transfer into the frequency domain with $s = 2j\pi f$

$$s \cdot c_p (T(s) - T(0)) = k_x \frac{dT(s)}{dx} + k_y \frac{dT(s)}{dy} + k_z \frac{dT(s)}{dz} + Q(s)$$

Organized by



Hosted by



In collaboration with



Supported by




eVS | 27 Model

The cell was modelled as a rectangular prism with 8 elements

The heat generation is supposed uniform.

The convection heat transfer coefficients were calculated using empirical correlations for free convection (Nusselt and Rayleigh numbers)



Organized by



Hosted by



In collaboration with



Supported by



EVs | 27

Test Setup

We used a battery cell testing system and a small test chamber to conduct the tests. The data was recorded using an Agilent 34972A data acquisition unit



Organized by



Hosted by




In collaboration with



Supported by



We used complex least square fitting to find the heat conductivity and heat capacity



Measured temperature rise

Cp (J/(kg K))	Kx (W/(m K))	Ky (W/(m K))	Kz (W/(m K))
1142	2.4	0.3	0.1

Organized by



Hosted by



In collaboration with



Supported by



eVS | 27 Observations

There was no available data from the manufacturer for the cell heat conductivity and heat capacity, making it hard to compare our results

In the literature :

- The cell heat capacity can be between 830 and 1150 J/(Kg K)
- The cell heat conductivity perpendicular to the electrode stack should be around 0.35 W/(m K)
- The cell heat conductivity parallel to the electrode stack can be anywhere from 10 to 100 times the perpendicular conductivity

Organized by



Hosted by



In collaboration with



Supported by



eVS | 27 Observations

There is a lot of influence on the results for two parameters :

- The calculated heat generation
- The calculated free convection boundary conditions

Organized by



Hosted by



In collaboration with



Supported by



eVS | 27 Conclusion

- We applied the TIS method in 3D to a large prismatic Li-Ion cell.
- We need a better heat generation model or equipment with higher capabilities at high current to increase the precision of the test
- The free convection resistance is in the same order as the wanted parameters. Good control of this resistance is needed for good characterization.

Organized by



Hosted by



In collaboration with



Supported by



We would like to thank the following partners for their contribution to the project

Enseignement supérieur,
Recherche, Science
et Technologie

Québec 



Questions?

Organized by



Hosted by



In collaboration with



Supported by

